

Make	Model	Body Style	Build Date	Model Code
	New			
	Updated			
	Unchanged			
Citroen	Nemo	<i>Van</i>	07 on	A50
	Berlingo	<i>Van</i>	96-02	A54
	Berlingo	<i>Van</i>	02 on	A56
	Dispatch	<i>Van</i>	95-03	A27
	Dispatch	<i>Van</i>	03-06	A57
	Dispatch	<i>Van</i>	07 on	A67
	Relay	<i>Van</i>	97-02	A53
	Relay	<i>Van</i>	02-06	A55
	Relay	<i>Van</i>	06 on	A65
Fiat	Fiorino	<i>Van</i>	08 on	8AF
	Doblo	<i>Van/Combi</i>	01 on	847
	Scudo	<i>Van/Combi/Platform Cab</i>	95-03	877
	Scudo	<i>Van/Combi/Platform Cab</i>	03-07	880
	Scudo	<i>Van/Combi/Platform Cab</i>	07 on	8B1
	Ducato	<i>Van/Combi/Platform Cab</i>	94-02	876
	Ducato	<i>Van/Combi/Platform Cab</i>	02-06	824
	Ducato	<i>Van/Combi/Platform Cab</i>	06 on	893
Ford	Fiesta Courier	<i>Van</i>	91-96	255
	Fiesta Courier	<i>Van</i>	96-01	261
	Escort	<i>Van</i>	90 on	249
	Ranger	<i>Pick Up</i>	99-03	297
	Ranger	<i>Pick Up</i>	06 on	217
	Transit	<i>Van</i>	85-94	252
	Transit	<i>Van</i>	95-99	256
	Transit	<i>Van</i>	00-06	296
	Transit	<i>Chassis Cab</i>	00-06	299
	Transit	<i>Van</i>	06 on	219
	Transit	<i>Chassis Cab</i>	06 on	2B1
	Transit/Tourneo Connect	<i>Van</i>	02 on	289
Isuzu	Rodeo	<i>Pickup</i>	04 on	3753
Iveco	Daily	<i>Van</i>	99 on	W52
	Daily	<i>Van</i>	06 on	W42
	Daily	<i>Platform</i>	06 on	W43
Land Rover	Defender	<i>Pickup</i>	96 on	3350
	Defender	<i>Pickup</i>	07 on	3360
LDV	Convoy	<i>Van</i>	96-06	5113
	Maxus	<i>Van</i>	05 on	5110
Mazda	B Series	<i>Pick Up</i>	99 on	I56
	BT-50/Drifter	<i>Pick Up</i>	07 on	I41
Mercedes	Sprinter	<i>Van</i>	96-00	355

Mercedes (cont'd)	Sprinter	Van	00-06	357
	Sprinter	Van	06 on	373
	Sprinter	Chassis Cab	00-06	358
	Sprinter	Chassis Cab	06 on	388
	Viano	Van	04 on	350
	Vito	Van	96-03	356
	Vito	Van	03-06	359
Mitsubishi	L200	Pick up	96-06	G56
	L200	Pick up	07 on	G64
Nissan	Kubistar	Van	03 on	Z98
	Pick Up	Pick Up	99-05	Z58
	Navarra	Pick Up	05 on	Z62
	Vanette	Van	88-96	Z31
	Primastar	Van	02 on	Z74
	Interstar	Van	02 on	Z50
	Cabstar	Pick Up	00-06	Z65
	Cabstar	Pick Up	06 on	Z94
Peugeot	Bipper	Van	07 on	B41
	Partner	Van	02-06	B58
	Partner	Van	08 on	B68
	Boxer	Van	02-06	B50
	Boxer	Van	06 on	B65
	Expert	Van	96-04	B54
	Expert	Van	04-07	B60
	Expert	Van	07 on	B70
Renault	Kangoo	Van	97-02	C50
	Kangoo	Van	03-08	C18
	Kangoo	Van	08 on	C60
	Trafic II	Van	01 on	C57
	Master	Van	98-03	C59
Seat	Inca	Van	96-03	Q52
Toyota	Hi-Ace	Van	96 on	Y57
	Hi-Lux	Pick Up	97-05	Y70
	Hi-Lux	Pick Up	05 on	Y65
Vauxhall	Corsa Van	Van	01-06	505
	Combo	Van	93-02	551
	Combo	Van	02 on	578
	Astra Van	Van	98-06	503
	Vivaro	Van	01 on	590
	Movano	Van	99-04	553
	Movano	Van	04 on	591
Volkswagen	Caddy	Van	95-03	680
	Caddy	Van	03 on	679
	Transporter	Van	91-03	686
	Transporter	Van	03 on	689
	Transporter Chassis Cab	Chassis Cab	03 on	694
	Transporter LT	Van	96-06	688
	LT Crafter	Van	06 on	690
	LT Crafter	Chassis Cab	06 on	694

TOTAL: 89 Audatex Commercial Models Available covering 17 manufacturers